



Maglocks are always connected to relay's Common and Normally closed contacts

WARNING: when using a maglock, it is required to place a pushbutton in series with the maglock power, in order to interrupt the lock in an emergency.

